




# Magic Bullet MB1001B Power Cord Replacement

Replacing the power cord on your Magic Bullet MB1001B.

Written By: Bridget Carr



## INTRODUCTION

Having trouble turning on your Magic Bullet? This guide will help you replace the power cord.


---



### TOOLS:

- [Spudger](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
  - [Basic Pliers](#) (1)
-

## Step 1 — Power Cord



- Remove the four rubber pegs from the feet on the base of the Magic Bullet using the spudger.

## Step 2



- Remove the four 14.0 mm Phillips head screws in the feet of the base of the Magic Bullet using the Phillips #1 screwdriver.



### Step 3




- Remove the black base plate.

### Step 4




- Remove the two 13.0 mm Phillips head screws from the white plastic cable guide using a Phillips #1 screwdriver.

## Step 5




- Remove the white plastic cable guide.

## Step 6



- Remove the two crimp caps from the end of the wires.
- ⓘ You will need to purchase new crimp caps and use pliers to crimp the new crimp caps on the connected wires during reassembly.

## Step 7



- Separate the black wires of the power cord from the red wires on the Magic Bullet base.
- ⓘ Be sure to mark which wires are connected before separating them to ensure that they are properly reconnected during reassembly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 07:49:02 AM.